

# Airwall - user's manual



1. Before you unpack the balloon, put the bag on an even surface.



2. Unpack the airwall and put it on the ground with the side with Velcro on top.



3. Next secure the clamps to the airwall.



4. Air starts to fill the tent. Remember not to cover the extractor fan.




5. Wait until the airwall is completely inflated.\*



6. Using the claps put the airwall vertically on the ground.



7. Put the other side of the rope into the ground.



8. Repeat the previous step and secure all ropes to the airwall and the ground. Regulate the stability of the airwall using the cord and ropes.



9. The last step is to anchor the airwall into the ground.

**\*\* INSTALLATION OF THE ADVERTISING MESH**, follow these steps before placing the screen:

Unpack the mesh and put it on one edge of the screen. Unfold the mesh, slowly attaching it to the screen.

When the mesh is properly attached it will suit perfectly on the second end of the screen. When the graphic is attached go to step 6.

**To undo the airwall, open the zipper. The dismantling is the other way around. Firstly, remove the pegs in order to avoid the airwall damage.**