

# Airgate - user's manual



1. After unpacking the airgate put it on the ground.



2. Next secure the clamps to the airgate.



3. Connect the plug socket in order to start inflating the airgate.



4. In order to secure the plug with the extension, put it into the airgate.



5. Close the zip placed on the base of the airgate.



6. Wait until the airgate is inflated.



7. After the gate is completely inflated secure the other end of the rope with a hammer and pegs into the ground.



8. Repeat the two previous steps and secure all ropes to the gate and the ground. Regulate the stability of the gate using the cord and ropes.



9. The last step is securing the base of the airgate using the pegs. Hammer the pegs through the peg-gaps into the ground.