Assembly instructions for Gobitent

Pull out the mast until you hear a „click", which means it will be locked. Twist the crank just as long as you feel a clear resistance. You should follow the conditions of the use described in the warranty and stick to the rules about the maintenance of the cover. The dismantling takes places in the reserve order.

MITKO Sp. z o.o.

Osiedle 1 Maja 16G | PL 44-304 Wodzisław Śląski | TIN: PL 6470509572
Tel. +48 32 444 66 16 | Fax: +48 32 757 09 20 | office@mitkoforevents.com | www.mitkoforevents.com

MITKO Sp. z o.o. is registered with the District Court in Gliwice, X Commercial Division of the National Court Register.
TIN: PL 6470509572 | CRO: 270708422 | NCR: 0000331770. Share capital in the amount of PLN 200 000,00 fully paid-up.
The Company is represented by chairman Mr Michał Mitko.